

Функція датчика CO2 для HRV

CH-HRVx.xKDC

CH-HRVxK2

CH-HRVxxK2

Функція датчика CO2 дозволяє автоматично підтримувати заданий рівень CO2 у приміщенні.

Для реалізації цієї функції необхідно встановити датчик CO2, фото 1 та виконати налаштування. Параметр 07 відповідає за бажаний рівень CO2 у приміщенні, рекомендоване значення A7, фото 2.

CO2 функція працює наступним чином — при перевищенні значення CO2 котре встановлено параметром 07 — агрегат автоматично вмикається і працює до тих пір поки значення виміряне датчиком CO2 не буде нижче за значення установлене в параметрі 07.

The CO2 sensor feature allows you to automatically maintain a set CO2 level indoors.

To implement this function, you need to install a CO2 sensor, photo 1 and make adjustments. Parameter 07 is responsible for the desired level of CO2 in the room, the recommended value of A7, photo 2.

The CO2 function works as follows - when exceeding the CO2 value set by parameter 07 - the unit automatically switches on and operates until the value measured by the CO2 sensor is lower than the value set in parameter 07.



Size (розміри), mm
85x85x26

Фото 1 / Photo 1



Φοτο 2 / Photo 2



Φοτο 3 / Photo 3